

# MIXING AND PATCHING INSTRUCTIONS

1. MIX A SOLUTION OF 1/2 LATEX CONCRETE ADHESIVE AND 1/2 WATER.
2. COMBINE SOLUTION WITH STONE DUST (IN SMALL QUANTITIES) TO A TOOTHPASTE CONSISTENCY.
3. APPLY THE PASTE TO THE CLEAN AND DRY SURFACE OF THE AREA TO BE PATCHED (ALLOW ENOUGH FOR SANDING).
4. ALLOW PASTE TO SET AND ADHERE TO STONE.  
(15 MINUTES TO 2 HOURS DEPENDING ON TEMPERATURE, HUMIDITY AND DEPTH OF PATCH.)  
(PATCHES OF EXCESS DEPTH – 1/2” OR MORE – MAY REQUIRE LAYERING PATCH TO DECREASE ”SET” TIME.)
5. WHEN THE PATCH HAS SET, SAND THE EXPOSED SURFACES AS REQUIRED. IT IS BEST THAT THIS BE DONE WITH A SANDING BLOCK (SANDPAPER ON A RIGID BACKER – TO PROTECT SHARP CORNERS FROM ROUNDING).
6. CLEAN SANDED SURFACES WITH CLEAR WATER AND ALLOW TO DRY.